

porodo



Porodo

Lifestyle LED Display Mini Water

Dispenser with Manual Folding 5W

SKU: PD-LFWD5W-WH

Table of Contents

Features.....	2
Package Contents.....	2
Attention.....	2
Specifications.....	2
Installation Method.....	3
Operation Instructions.....	3
Maintenance and Cleaning.....	3
Warranty.....	4
Contact Us.....	4

Before installing and using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Features

- 1. Foldable Design
- 2. Large LED Display
- 3. Quantitative Pumping Options: 200ml, 600ml, 800ml
- 4. Silent Operation with minimal noise
- 5. Power Indication
- 6. Ideal for use with bottled mineral and purified water

Package Contents

Main Unit ×1
USB Cable ×1
Inlet Hose ×1

Attention

- 1. Avoid utilizing this product for the pumping of oil, alcohol, hot water exceeding 55°C, and any corrosive substances.
- 2. It is not advisable to cleanse this product by direct application of water.
- 3. Prior to dispatch, each product undergoes a quality assurance test that includes pumping water. Consequently, a small amount of residual water may be present within the product upon receipt.

Specifications

Rated Voltage	5V DC
Rated Power	4W
Battery	1200mAh
Charging Port	USB Type-C
Delivery Capacity	200ml, 600ml, 800ml

Installation Method



Install and fix the inlet hose.



Secure the unit on a water bottle.



Open the spout.



The device is ready to use.

Operation Instructions

1. Ensure the product is fully charged before initial use.
2. The product's power level is indicated by four lights; when all four are illuminated, the product is fully charged.
3. By pressing the normal operation button, the product will pump continuously for three minutes.
4. Utilize the quantitative selection button to choose a dispensing volume of 200mL, 600mL, or 800mL. After selection, a brief two-second pause is required before the liquid is dispensed.
5. The product's operation can be halted by pressing the same button again.

Maintenance and Cleaning

1. The Silicone Hose should be boiled for a few minutes before initial use and subsequently every two months to ensure optimal hygiene.
2. It is recommended that the Silicone Hose be replaced every six months to preclude any hygiene-related concerns.
3. Ensure there is no water residue inside the unit before it is stored for an extended period.

Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://porodo.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.porodo.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **[porodo](https://www.instagram.com/porodo)**